

7.4.2 Maintenance Mode (メンテナンスモード<0A, 0B>/S)

要約: ホスト→eGM:

- オペレータの介入を知らせる;
- ドアオープンの警告を出させない;

(行政当局の要求あるとき)
→ 許可なくeGMへアクセス時、警告を出す必要のないとき; この機能は実装しなくてもよい;

7.4.2 Maintenance Mode
Maintenance Mode is a feature used in some jurisdictions to allow the host to inform the gaming machine that an operator is properly logged into the system, to prevent a door open alarm on the gaming machine from sounding. Normally, long poll 0A is sent when an operator inserts a special card into the SMIB and enters a code. Long poll 0B is issued when the card is removed. Please consult your jurisdiction as to the need for this functionality. If you do not have a requirement to sound an alarm for unauthorized slot machine access, you probably do not need to implement this feature.

